
# Rasland

### คู่มือการติดตั้ง RA BLACK-BLACK

**MANUAL RA BLACK-BLACK-2023** 



### การไล่น้ำก่อนทำการติดตั้ง

แนะนำอย่างยิ่งสำหรับห้องน้ำใหม่ ที่ยังไม่เคยใช้งาน หรือในทรณีเปลี่ยนสินค้าใหม่

- 1. ไล่น้ำออกจากท่อที่ทำแพง ที่ได้เตรียมไว้ในทารใส่วาล์ว เปิดปิดน้ำ โดยการเปิดวาล์วน้ำหลัก ในห้องน้ำให้สุด เพื่อใช้แรงน้ำ ไล่สิ่งแปลกปลอมให้ไหลออกจากท่อทำแพง โดยใช้ดังน้ำ หรือวัสดุในการปิดกันน้ำทระเด็น โดยไม่ต้องใส่วาล์วใดๆ ที่ทำแพง เพื่อเป็นการไล่ฝุ่นละออง ตะทรัน ตะกอน เศษทราย หรือเศษหินที่ค้างอยู่ในท่อออก
- 2. เปิดน้ำทั้งไว้เป็นเวลา 30 วินาที เพื่อรอให้น้ำพาสิ่งแปลกปลอม ไหลออกมาจากท่อให้หมด ทั้งนี้เพื่อไม่ให้ สิ่งแปลกปลอมต่างๆที่มากับท่อน้ำ อดตันฝักบัวหรือวาล์วน้ำ
- 3. ปิดวาล์วหลักในห้องน้ำ และประกอบสินค้าตามการติดตั้งด้านล่าง

### วิธีการติดตั้งสินค้า

- ใส่ประเท็นยางระหว่างข้อต่อ เพื่อไม่ให้น้ำซึม และประกอบข้อต่อน้ำเข้า
   (i) เข้ากับด้านล่างของตัวเปลี่ยนทิศทางน้ำ โดยใส่ประเท็นยางระหว่างข้อต่อเพื่อไม่ให้น้ำซึม ประกอบตัวแปลงน้ำเข้า (J) เข้ากับไดเวอร์เตอร์ (D)
- 2. วัดระดับและทำเครื่องหมายในการเจาะรูที่ผนัง เพื่อทำการเจาะรูใส่แป้นยึดทำแพง (H) โดยวัดพร้อมทันทั้งสองจุด
- 3. เจาะรูที่ทำแพงตามรูที่ให้ไว้ในแป้นยึด โดยต้องระวัง !!!! อย่าให้น๊อต ยึด ทะลุทำแพงไปโดนท่อน้ำ ที่เดินไว้ภายในทำแพงเด็ดขาด
- 4. ใส่ตัวแป้นยึดและครอบตัวยึดทำแพง เข้าทับท่อลอยแบบตรงและใส่ชั้นวางของ ด้านล่างของขอแขวน
- ใส่สายฝักบัว (E) โดยใช้ข้อต่อด้านสั้น กว่าของสายฝักบัว ต่อกับตัวเปลี่ยนทิศทางน้ำ โดยใช้มือหมุน ควรใส่ประเท็นยางกันน้ำซึมด้วย และด้านยาวกว่าต่อกับฝักบัวมือ (C) โดยใช้มือหมุน ควรใส่ประเท็นยางกันน้ำซึม (สายขนาดยาว 150 ซม.)
- 6. แขวนฝักบัวมือเข้ากับขอแขวนฝักบัวที่อยู่ที่ท่อลอยแบบตรง (B)
- 7. หมุนหัวฝึกบัวท้านแข็ง (A) เข้าทับข้อต่อฝักบัวท่อลอย โดยใส่ประเก็นทันน้ำซึม และใช้มือหมนให้แน่น
- 8. ใส่สายฝัทบัว (F) โดยใช้ข้อต่อด้านสั้นทว่าของสายฝัทบัว ต่อกับปลายด้านล่างสุดของข้อต่อ โดยใช้มือหมุน ควรใส่ประเท็นยางทันน้ำซึมด้วย และด้านยาวทว่า ต่อกับรูน้ำออก ของเครื่องทำน้ำอ่น (สายขนาดยาว 120 ซม.)
- 9. เปิดวาล์วน้ำใช้งานได้ตามปกติ

### วิธีการทำความสะอาด และดูแลรักษา

- 1. ห้ามใช้น้ำยาล้างห้องน้ำ ในการทำความสะอาดสินค้า เพราะจะทำให้ผิวของสินค้าเสียหาย
- 2. ไม่ควรใช้วัสดุผิวหยาบขัดทำความสะอาด ต้องใช้ฟองน้ำเท่านั้นในการเช็ดทำความสะอาด
- 3. ใช้น้ำยาล้างจานผสมน้ำ ในการล้างให้ขึ้นเงา
- 4. หากใช้งานแล้ว รูน้ำที่ฝิกบัวมือ หรือฝักบัวก้านแข็งตัน สามารถใช้นิ้วถูปุ่มยาง ในขณะเปิดน้ำ เพื่อให้ตะทรันที่อุดอยู่ หลุดออกจากรูฝักบัว
- 5. ไม่ควรดึงสายฝักบัวในการปรับระดับความสูงของขอแขวน เพราะจะทำให้สินค้าเสียหายได้


#### การรับประกัน

- 1. สินค้ารับประทันเฉพาะน้ำรั่วซึม ที่วาล์วเปิด ปิดน้ำ เท่านั้น โดยรับประทันน้ำไม่รั่วซึม เป็นเวลา 5 ปี
- การรับประทัน ไม่รับประทันในทรณีที่การซึมของน้ำเกิดจาก การติดตั้งผิดวิธี อันเป็นการทำลาย ใส่ในของวาล์ว หรือสิ่งแปลกปลอมอุดตันภายใน หรืออุดตันจากตะทรันน้ำ หรือ สภายน้ำ ที่ไม่สะอาด
- 3. การรับประทัน ทางบริษัทฯ จะรับผิดชอบไม่เทินมูลค่าของสินค้า โดยไม่รับผิดชอบ ความเสียหายอื่นๆ นอกเหนือจากตัวสินค้า
- ในการเคลมสินค้า ต้องแสดงใบเสร็จ ในการซื้อเป็นสำคัญ มิฉะนั้นทางบริษัทฯ สงวนสิทธิ์ในการไม่เคลมสินค้า

## Rasland

### INSTALLATION GUIDE RA BLACK-BLACK

**MANUAL RA BLACK-BLACK-2023** 



### Run water through the in-wall-pipe before installing products

highly recommend for the new bathroom that has never been used before

- Run water through the in-wall-pipe by opening the water valve and let water runs
  out from the pipe before installing any parts of products to the pipe. Please use
  any containers to block the water splash from the pipe during the run through.
  This process is highly recommended in order to wash out the deposit or any sands
  in the water pipe so that it will not cause damage to the products.
- Run through process would take around 30 seconds by opening the valve all the way open so that the flow will bring out all the deposits out from the in-wall-pipe.
- 3. Close the main valve and then follow the installation guide below.

### **Installation** guide

- Measure the height at the position that the fixing (H) in order to drill holes on the wall.
- 2. Drill holes on the wall. (Please be careful of the water pipe inside the wall that the screws are not supposed to cause any damage to the in-wall-pipe)
- 3. Screw fixing sets on the wall. Put the pipe on the bracket by using the bracket to lock the pipe. Then put in the bracket cover.
- Put diverter to the end of the pipe by putting an 0-ring in between.
   Then, screw the pipe to the wall.
- Put the shower hose (E) by putting the shorter nut with the diverter and the longer nut with hand shower (C). Make sure that the 0-ring is also put between the angle in order to prevent water leakage.
- 6. Hang the hand shower with sliding hook on the straight pipe (B).
- 7. Put the overhead shower (A) with pipe by putting an 0-ring in between the angle to prevent water leakage.
- 8. Put the shower hose (F) by putting the shorter nut with the low-end of the pipe and the other and of the hose to outlet of the Water heater unit.
- 9. Turn on the water valve and enjoy the Shower Rain.

### Clean guide and maintenance

- Do not use acid chemical to clean the products because it will ruin the surface of the chrome plated.
- Do not use rough surface material to rub or clean the product. Soft material is highly recommended.
- 3. Use dish washing chemical mix with some amount of water to shine the product.
- 4. In the case that the deposit blocks holes on the overhead shower or hand shower, the deposit can easily be removed by turning on the water and rub on the rubber head.
- 5. Do not adjust the height of the sliding hook by pulling the shower hose but use hold the button on the hook while sliding hook up and down.

#### **Guarantee conditions**

- The warranty is only for the leakage of the water valve only (diverter). The period is counted from the date of purchase for 10 years.
- The warranty is not effective if the leakage caused by mis-installing or deposit or lime that caused by water condition.
- The company will be responsible the damage that is not exceed the price of the product and will not be responsible other things other than the product itself.
- 4. In order to claim the warranty, the sales receipt must be presented otherwise the company has the right to refuse the claim.